



Entry Wizard 2.0 Parts Breakdown




NO.	PART NUMBER	DESCRIPTION
1	36573	Entry Wizard 2.0 Decals (package)
2	08646-01	Printer Paper
3	72005	Keypad
4	75825-2	Credit Card Swipe
5	26259	Coin Acceptor
6	16100	Bill Acceptor
7	17-35003201	Coin Return Cup
8	A0133-15	High Security Bill Acceptor Cover
9	24074 24470	Cam Key Locks Cam Keys
10	72026	Wash Selection Buttons
11	08505	Information Screen
12	A0133-14 59909	High Security Door High Security Hinge
13	42010 42012	Light Fixture & Bulb Bulb Only

Parts list cont...



NO.	PART NUMBER	DESCRIPTION
1	08504	20" Keyboard Cable
2	49367	Lock Bolt
3	A0133-35	PC Cover
4	8206-9	Horn
5	17-35003201	Coin Cup
6	16100 Model #2612	Bill Acceptor Box
7	26259	Coin Acceptor
8	75825-2	Credit Card Acceptor
9	8683	Door Hinge (main)
10	72005	Keypad
11	08504	21" Keypad Cable

Parts list cont...



NO.	PART NUMBER	DESCRIPTION
1	08657	Cycle Control Box
2	08646-00	Axhiom Printer
3	24095	Heating Pad (optional)
4	08648	POS 4000 B&B Optic Repeater (optional)
5	08668	Transformer
6	A0133-18	Coin Box
7	40038 40030	Cabinet Fan Finger Guard
8	08551	Coin Hopper
9	08649	Radio Interference Filter
10	75815	Surge Protector
11	08687	Modem Cable
12	33570	Modem
13	40039	Off/On Switch
14	A079-3	Interior High Security Lock Nuts
15	68120	Thermostat (optional)
-	08511	Heater Kit (optional)